


Installation guide - Spare parts and accessories

Solenoid valve - Manual override unit


Type EV220B 15 - EV220B 50

032R9311

032R9311



A




Total no. = 4

B



Total no. = 2

C



Total no. = 1

D



Total no. = 1

