




Care and use instructions

CAUTION

- Product is NOT designed for hot liquids.
- Use only with cold liquids.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed on completely.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT overfill. Fill liquids to just below the threading in the body.
- DO NOT continue to use product if damaged.
- DO NOT use cleaners containing bleach, chlorine, abrasives, and/or other harsh chemicals.
- DO NOT continue to use product if damaged.

USAGE RECOMMENDATIONS



To fill with ice

To fill with water

CLEANING INSTRUCTIONS


- Wash thoroughly before first use.
- It is NOT necessary to remove the silicone sleeve from the bottle for washing.

Copyright © 2015 contigo, All rights reserved.

Kambukka bvba | Torenplein 7.16.1 | 3500 Hasselt | Belgium

contigo®

- RINSE IMMEDIATELY AFTER EACH USE.
- Cap, lid and plastic body with silicone sleeve are top-rack dishwasher safe.



- If washing by hand, wash body, lid & cap with warm water and a mild detergent. Rinse both lid and body thoroughly before use.
- ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.

