


F007J PARTS LIST FOR FBP GROUP P.1/1




針距	成品尺寸	喇叭代號
5.6	9 (mm)	FBP01A
5.6	10	FBP01B
6.4	12	FBP01C

1 2 3 4 5
FOR F007J/F007JD/F858J/F858JD


10/07/01

F007J PARTS LIST FOR FDC GROUP P.1/1


A




B



C




D




E

F007J PARTS LIST FOR FDE GROUP P.1/1


A




B




C




D



E




PARTS LIST FOR FE-J GROUP 系列圖 1




F007J PARTS LIST FOR FE - K GROUP P.2/3

FE202-A1


A




B




C




D



E



F007J PARTS LIST FOR FE - K GROUP P.3/3



LS-A


A

B

C

D

E



1


2

3

4

5

PARTS LIST FOR FFC-J GROUP P.1/1




FOR F007J/F858J


The device of LS-A is shown for indication only, this device is not including it.

11/07/28


F007J PARTS LIST FOR FFD - J GROUP 1



F007J PARTS LIST FOR FFD-J GROUP P.2/3



PARTS LIST FOR FFD GROUP 系列圖 3



1

2

3

4


5

FOR F007J/F858J


11/07/28

The device of LS-A is shown for indication only, this device is not including it.


F007J PARTS LIST FOR FFP GROUP P.1/3



F007J PARTS LIST FOR FFP GROUP P.2/3



PARTS LIST FOR FFP GROUP 系列圖 3




1 1 2 1 3 1 4
FOR F007J/F007JD/F858J/F858JD

11/07/29

The device of LS-A is shown for indication only, this device is not including it.

PARTS LIST FOR FQ GROUP P.1/1



1

2

3


4

5

FOR F007J/F858J
★USE FOR F007J/F858J/UTG(UTH,UTJ,UTK)


10/07/28

F007J PARTS LIST FOR FR-J GROUP P.1/3




FR	FR/FEC(FAC)
不用	* FR42
不用	* FR43
* GFR52	* GFR55


F007J PARTS LIST FOR FR-J GROUP P.2/3



F007J PARTS LIST FOR FR-J GROUP P.3/3




PARTS LIST FOR FSM-J GROUP 系列圖 1



PARTS LIST FOR FSM-J GROUP P.2/6

機型 MODEL	零件編號 PARTS NO
W222-240-4	FSM25 FSM24
W222-248-4	FSM25 FSM24
W222-364-4	FSM25P FSM24P




1 FOR F007J/F007JD/F858J/F858JD

註：△輪 FSM220/222 為備品

12/05/08

PARTS LIST FOR FSM-J GROUP 系列圖 3

1
FOR F007J/F858J


2

3

4

5


PARTS LIST FOR FSM-J GROUP 系列圖 4



1 FOR F007J/F007JD/F858J/F858JD 2

11/05/06

PARTS LIST for FSM-K GROUP P.5/6




註：
W222-240-4 喇叭標準配備為
FQ305 成品尺寸為 $1/2''$.
W222-248-4 喇叭標準配備為
FQ305P, 成品尺寸為 $5/8''$.
W222-364-4 喇叭標準配備為
FQ305Q, 成品尺寸為 $3/4''$.


1 2 3 4 5

PARTS LIST FOR FSM-J GROUP 系列圖


6




F007J PARTS LIST FOR FSP GROUP P.1/1



F007J PARTS LIST FOR FSQ GROUP P.1/1




F007J PARTS LIST FOR FSR GROUP P.1/2




F007J PARTS LIST FOR FSR GROUP P.2/2


A



B





C



E


F007J PARTS LIST FOR FV GROUP P.1/1






PARTS LIST FOR FWP-J GROUP 系列圖

2













F007J PARTS LIST FOR FWP GROUP P.3/4




F007J PARTS LIST FOR FWP GROUP P.4/4


KW40E-A3



F007J PARTS LIST FOR FY—J GROUP P.1/3



PARTS LIST FOR FY-J GROUP 系列圖 2



1


2

3


4

5


F007J PARTS LIST FOR FY—J GROUP P.3/3



F007J PARTS LIST FOR LSA GROUP P.1/1




F007J PARTS LIST FOR UTG(UTH) GROUP P.1/9



FOR F007J/F007JD/ F858J/F858JD
★USE FOR F007J/F858J-FQ/F007JD/F858JD-FQ

10/12/28


F007J PARTS LIST FOR UTG(UTH) GROUP P-2/9



FOR F007J/F007JD/F858J/F858JD
 \star USE FOR F007J/F858J-FQ/F007JD/F858JD-FQ

10/12/28

F007J PARTS LIST FOR UTG(UTH) GROUP P.3/9



1

2

3

4

5


FOR F007J/F007JD/F858J/F858JD
* USE FOR F007JD/F858JD

■ FOR H馬達
□ FOR P馬達


10/12/28

F007J PARTS LIST FOR UTG(UTH) GROUP P.4/9


A




B



C



D



E

- [1] LIFT PRESSER FOOT
- [2] LOOP TRIMMER
- [3] TOP CUTTER
(WIPER)

F007J PARTS LIST FOR UTG(UTH) GROUP P.5/9


A

B


C

D

E



F007J PARTS LIST FOR UTG(UTH) GROUP P.6/9




F007J PARTS LIST FOR UTH-J GROUP P.7/9

A

FOR LEFT SIDE

B




C


D

E


F007J PARTS LIST FOR UTG-J GROUP P.8/9




F007J PARTS LIST FOR UTG(UTH) GROUP P.9/9




F007J PARTS LIST FOR UTJ-J(UTK-J) GROUP P.1/9



F007J PARTS LIST FOR UTJ-J(UTK-J) GROUP P 2/9




F007J PARTS LIST FOR UTJ-J(UTK-J) GROUP P.3/9




F007J PARTS LIST FOR UTJ(UTK) GROUP P 4/9



A




B





C



D



USE FOR F007JD



E


UT810-A1

1 FOR F007J/F007JD/F858J/F858JD
2 * USE FOR F007JD/F858JD


4 ■ FOR H牌馬達

5 10/12/27


F007J PARTS LIST FOR UTJ(UTK) GROUP P 5/9




F007J PARTS LIST FOR UTJ-J(UTK-J) GROUP P 6/9




F007J PARTS LIST FOR UTK J GROUP P.7/9




F007J PARTS LIST FOR UTJ J GROUP P.8/9




F007J PARTS LIST FOR UTJ-J(UTK-J) GROUP P.9/9



F007J PARTS LIST FOR WP GROUP P.1/2



F007J PARTS LIST FOR WP GROUP P.2/2



FOR F007J/F007JD/C007J/C007JD/S007K/S007KD
FOR F858J/F858JD/C858J/C858JD

10/07/01

1 2 3 4 5